
Bergmans Mechatronics LLC

LabVIEW-Based Instrumentation for Large-Scale Combustion Diagnostics

John Bergmans
Bergmans Mechatronics LLC
www.bergmans.com

National Instruments LabVIEW User Group Meeting
Santa Ana, CA
May 29 2008

- Bergmans Mechatronics LLC specializes in the development of custom LabVIEW software and instrumentation products
- Current BML products for large scale combustion diagnostics
 - LTS-100 Laser Temperature Sensor and
 - Laser Alignment System
- Objective of presentation: Illustrate use of LabVIEW and NI hardware for specialized instrumentation applications

LTS-100 Laser Temperature Sensor

BML




Processing Unit in
Power Plant Terminal Room


- Employs Tunable Diode Laser Absorption Spectroscopy (TDLAS) for Measurement of gas temperatures up to 3000 °F
- Designed for temperature measurements in power plant boilers and refinery heaters
- Testing performed along 48 foot path at Ameren Sioux Station near St Louis, MO
- LabVIEW-based software
- Core TDLAS technology developed by MetroLaser, Inc., Irvine, CA

LTS-100 Laser Temperature Sensor employs two-line TDLAS to measure temperature and H₂O concentration

Calibration testing using flat flame burner:



Detector signal during calibration (TC = 2578 °F)




Absorbance:

$$\alpha_{\lambda} = -\ln\left(\frac{I(\lambda)}{I_o(\lambda)}\right)$$


With constant temperature along beam path, ratio of absorbance under two absorption peaks is a function of temperature:


$$R = \frac{A_1}{A_2} \approx \frac{S_1(T)}{S_2(T)}$$

Typical Calibration Spectra




Calibration Curve





LTS-100 and
Calibration Apparatus





Temperature Measurements
on Flat Flame Burner

Laser Alignment System

BML


- Computer controlled two-axis scanner
- Angular resolution: 0.0069° (0.069" at 48 feet)
- Range of motion: $\pm 13.7^\circ$
- Two operating modes: Raster Scan and Optimization



User Interface


BML


- 6.4" touch screen display
- Multi-layer tabs allows easy access to all system controls and displays
- Intensity plot for visualization of alignment process



LTS-100 Hardware Overview

BML





Ameren Sioux Station Testing

BML


- Located north of St Louis, MO, on Mississippi river
- Two, coal-fired, cyclone units
- Each unit nominally rated at 485 MW



Ameren Sioux Station Overview


BML

- LTS-100 tested on Unit 1
- Beam passed from side to side over 48 foot width of boiler
- Testing performed from end of Aug 2007 to beginning of Sep 2007
- Possible applications for temperature measurement - slag prevention and SNCR support



Installation at Sioux Station

BML






Processing Unit in
Terminal Room



Detector Optics Enclosure
on Boiler


Temperature and Load Data

BML



Temperature and Load Data


BML



Potential Error in Baseline Fit


BML

Full scale detector signal and baseline at 2637 °F



Recent Progress in Baseline Fitting

BML



Laser Alignment System for TDLs


BML

- Interfaces to a Unisearch Associates LasIR TDL-based NH₃ monitor
- Enables continuous beam alignment despite duct wall movement
- Based on LTS-100 hardware and software







System Schematic


BML



Legend

-  Fiber Optic Cable
-  Coax Cable
-  Control Cable
-  Beam Path

LasIR Signal Strength Measurement




Laser Alignment System

BML



System testing with NH_3 test cell at University of California Riverside, CE-CERT

- Sponsored by Electric Power Research Institute (EPRI)
- Results:
 - 1) System can maintain alignment in presence of large detector movements
 - 2) LAS does not interfere with LasIR measurement accuracy



Launch Optics Enclosure


BML



Full Scale Testing

BML


- 28' foot path downstream of boiler at mid-western power plant
- Sample beam movement: $0.2^\circ = 1.2''$ at 28'
- Sponsored by EPRI




Effect on Beam Power Density

BML

- For manually aligned system with 1.2" of detector movement, spot size must be 3.4" diam (9.1 in² area)
- Auto-aligned system, spot size can be 1" diam (0.8 in² area)
- Resulting power density of manually aligned system is 8.6% of auto-aligned system



- For manually aligned system, increasing divergence angle increases availability
- Divergence angle is limited by minimum allowable signal strength




- LabVIEW development environment and PC and NI hardware are well-suited for rapid prototyping of instrumentation products
 - straightforward development of robust, user-friendly code
 - readily available, high-performance hardware
 - easy to interface software to hardware
- For mass production / cost sensitive applications, consider
 - Hardware: microcontroller, DSP
 - Software: C code or LabVIEW Embedded modules for Blackfin / ARM / DSP

LTS-100 Hardware Overview

BML

Interior of Interface Unit



LTS-100 Hardware Overview

BML

Custom, low-cost DAQ breakout board

